

ATTACH TRUSS TO COLUMN
WITH (2) 1/2"Øx5 1/2" BOLTS
AND NAIL WITH (2) 20d NAILS
PER BOLT

DEPTH OF TRUSS
HEEL MINUS 2"

#1 SP .60 CCA
3-PLY TREATED
COLUMN

ATTACH TRUSS TO COLUMN
WITH (2) 1/2"Øx5 1/2" BOLTS
AND NAIL WITH (2) 20d NAILS
PER BOLT

ADJUSTING BLOCK
BETWEEN TRUSS HEEL
AND CENTER PLY OF
COLUMN TO BE FIELD
CUT TO FIT

